

# Installation & set up



## Install

your Smart Plug and Smart Bulbs.

(the plug is required to enable out of home and voice control)



## Screw In

and power on your Smart Bulbs

### Tip:

*Having trouble connecting?*

*Move your smart plug closer to your router to commission.*



**Download**  
the  
CYNCR App.



## Add

your Smart Plug and Smart Bulbs to the same room/space within the CYNCR App.



## Enable

voice control by following the directions in the Settings tab of the CYNCR App.

For setup help, visit [cyncsupport.gelighting.com](https://cyncsupport.gelighting.com) or call 1-844-302-2943

## Let's get plugged into what your Smart Plug + Smart Bulb can do together

- 1** Schedule your lights to turn off at night.  
Go to **CYNCR App** and schedule the time and days of the week to turn off lights and devices under **Scenes**.
- 2** Turn on your desk fan and lights on your way home from work.  
Go to the **CYNCR App** and **toggle on** your Smart Bulbs and Smart Plug from your smart phone.
- 3** Can't remember if you turned off the curling iron and bathroom lights?  
Go to the **CYNCR App** to check the status of your Smart Bulbs and Smart Plug. **Toggle off** your Smart Bulbs and Smart Plug from your smart phone to turn off devices away from home.

Connect to your Amazon Alexa or Google Assistant device to control your lights and devices with your voice.

Try these commands:

Hey Google,  
I'm home.

Alexa,  
turn off the living room.

Alexa,  
good morning.

## Smart Plug

### FCC Compliance Statement Compliance Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment.

### RF Exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 8 inches during normal operation.

### RF Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This transmitter must be installed to provide a separation distance of at least 8 inches from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

## Smart Plug

**⚠ CAUTION - High Voltage - Disconnect power supply before servicing**

Operation temperature: 0-40°C

Type 1 Enclosure

IP20

Pollution Degree 2

Impulse Voltage: 1500V

Type 1.B action

Indoor use only.

GE is a trademark of General Electric Company.  
Used under trademark license.